

NAD Electronics

M51 Command List (RS232 and Ethernet)

Notes

- Send a Carriage Return <CR> before and after each command
- In addition to using the <=> operator, each [Prefix].[Variable] can be incremented, decremented, or queried by using <+>, <->, or <?> operators.

Main.Mute	Operators: =/+/-/?
------------------	--------------------

Possible Values:

- Off
- On

Description: turn mute off

Example: <CR>Main.Mute=Off<CR>

Main.Polarity	Operators: =/+/-/?
----------------------	--------------------

Possible Values:

- Reversed
- Positive

Description: change polarity to reversed

Example: <CR>Main.Polarity=Reversed<CR>

Main.Power	Operators: =/+/-/?
-------------------	--------------------

Possible Values:

- Off
- On

Description: Turn power off

Example: <CR>Main.Power=Off<CR>

Main.Source	Operators: =/+/-/?
--------------------	--------------------

Possible Values:

- PC LINK
- HDMI 2
- HDMI 1
- OPT
- COAX
- AES

Description: Change source to PC Link

Example: <CR>Main.Source=PC LINK<CR>

Main.Version	Operators: ?
---------------------	--------------

N/A

Description: Query the version number

Example: <CR>Main.Version?<CR>

Main.Volume

Operators: =/+/-/?

Possible Values:

range_-90_10_1

Description: Change volume

Example: <CR>Main.Volume=range_-90_10_1<CR>